

Fitting instructions for 3033 FORD TRANSIT 2000-

1. Remove the side brackets from the center bar and place it on the door pillar. Measure the correct height (680-685mm) and drill the holes with 3,5mm bit.
2. Fit the side brackets on the vehicle as follows:
 - 2.1. use 4,8 x 19mm screws to fit side bracket from the holes which are behind the door pillar
 - 2.2. use 4,8 x 25mm screws to fit the side bracket from the holes which are on top of the door pillar.
3. Fit the visor on the side brackets. Adjust the visors angle and tighten all screws.
4. Fit the nut cover hats and cover collar hats.
5. Mount the warning label on a place where the driver can see it.

Remember to tighten all screws after few hours drive and every 6 months.

WARNING!

The speed limit for the vehicle with the visor mounted is 130 km/h.
If you drive constantly faster than 130 km/h the visor may tear off!

**ANY NON-COMPLIANCE WITH THESE REGULATIONS CAUSE NO
RESPONSIBILITY TO THE MANUFACTURER OF ANY COSTS AND DAMAGES.**

