

3047 FITTING INSTRUCTIONS

1. Place the sun visor on the vehicle. Place the side brackets 80mm from the top of the windscreen. Mark the hole positions. Drill the holes which are inside of the door pillar with 2,5 mm bit and the holes which are on the pillar with 3,5 mm bit.
2. Mount the visor / side brackets on the vehicle (note the 4,8 x 20mm screws should be mounted on the pillar), adjust the angle of the visor and tighten all screws.
3. Fit the cover hats on the screws and nut cover hats.
4. Mount the warning label on a place where the driver can see it.

Remember to tighten all screws after few hours drive and every 6 months.

WARNING!

The speed limit for the vehicle with the visor mounted is 130 km/h. If you drive constantly faster than 130 km/h the visor may tear off!

ANY NON-COMPLIANCE WITH THESE REGULATIONS CAUSE NO RESPONSIBILITY TO THE MANUFACTURER OF ANY COSTS AND DAMAGES.

