



Fitting Instructions

Next Gen Scania R/S Highline

Have technical questions or need fitting advice?
Contact Kuda UK - 01449 744174

Step 1.



Open centre front locker and remove rubber mat. This will expose installed factory loom and plug.

Step 2.



Locate fixing frame using lugs located on forward edge and those present in the locker floor.

Step 3.



The front of the frame will line up with 2 holes in the locker floor. These holes have inserts which require a 6mm tap to add thread to the insert. **MUST** be done Gently.

Step 4.



Insert 2 x 6mm bolts into these newly threaded holes. On the offside fixing, you will need to locate the earth of the installed loom as shown.

Step 5.



Screw in 2 x M6 bolts (one per side) to each of the rear corners of the microwave. Screw to the end of the thread.

Step 6.



Plug in loom then slide microwave along brackets to locate the rear bolts at the rear of the brackets. You should angle the microwave as shown to lift over the front bracket slots.

Step 7.



Pivot the microwave back and align the 2 front bolt holes. Secure with supplied bolts and ensure these are tightened fully.

Step 8.



Check all fixings are secure to avoid vibrations.