

Step 1.

Remove the factory drawer and frame from under the bunk.

Step 2.

Secure the supplied metal bar to the forward fixings in the floor of the cab with 2 x M8 bolts and washers.

Step 3.

Fix the fridge panel to the metal bar using the 2 x supplied quick screws and 2 x M6 washers.

Step 4.

Secure the fridge using 4 x supplied M6 bolts, washers and spring washers.

Wiring.

Each fridge is supplied with an in-line fuse holder and fuse and a 300mm fly lead. We suggest the use of single core cable to wire the fridge back to a permanent live.

