

# Scania P Series Fridge Fitting Instruction

## Step 1.

Remove any factory fitted drawer from the centre of the engine tunnel under the bunk.

## Step 2.

Cut out the floor section as shown in picture. 500mm Wide - Measurement Shown. Cut from front to back.

## Step 3.

Remove raised floor lugs as shown in picture.

## Step 4.

Attach "L" shaped legs to the front bottom edge of the fridge

## Step 5.

Position fridge under the bunk, mark and drill through the plastic side panels of the bunk.

## Step 6.

Attach large "L" shaped brackets to fridge and bolt through the bunk panel and floor as shown.

