



24v Microwave

# VOLVO V3 GLOBETROTTER



Part Number :- VOLGLO



Locate microwave in rear locker.

Mark locker floor for drilling locations of side brackets.

Ensure side brackets are correct height to allow microwave door to open once fitted in locker.

Drill locker floor and fix brackets to floor with screws supplied.

## Wiring Option



Part Number :- LONGLOOM

## Fitting Kit Included

