

VOLVO V4 GLOBETROTTER / XL



Part Number :- VOLGLO4



Cradle Fitting.

Remove locker door and runners.

Align microwave in locker with replacement shroud panel.

Drill holes in locker floor.

Fit cradle to floor of locker, using screws & nyloc nuts.

Slide microwave between cradle ends, locating screws in side of microwave into slots in cradle.

Push microwave backwards and tighten front screw to lock in position.

Fit replacement shroud panel around microwave, securing with self tapping screws

Wiring Option



Part Number :- LONGLOOM

Fitting Kit Included

