



VEPRO OY

3124 VW Caddy / Caddy Kombi FITTING INSTRUCTIONS

1. Place the sun visor on the vehicle. Place the side brackets 610-620 mm from the bottom of the A-pillar. Mark the hole positions. Drill the holes with 3,0 mm bit. **But some sikaflex 252 around and in the holes and on the area where the sidebracket is mounted.**
2. Mount the visor / side brackets on the vehicle, adjust the angle of the visor and tighten all screws.
3. Fit the cover hats on the screws and nut cover hats. **But some sikaflex 252 around the sidebracket to prevent water going between the sidebracket and A-pillar!**
4. Mount the warning label on a place where the driver can see it.

Remember to tighten all screws after few hours drive and every 6 months.

WARNING!

The speed limit for the vehicle with the visor mounted is 130 km/h.
If you drive constantly faster than 130 km/h the visor may tear off!

**ANY NON-COMPLIANCE WITH THESE REGULATIONS CAUSE NO
RESPONSIBILITY TO THE MANUFACTURER OF ANY COSTS AND DAMAGES.**



Osoite/Address
Tehtaankatu 21,
11710 RIIHIMÄKI
FINLAND

Puhelin/Telephone
+ 358 19 724 000

Telefax
+ 358 19 720 765

Pankki/Bank
OKO 539602-254945
Sampo 800016-70104554
FI09001798