

VOLVO FM / FH sun visor fitting instructions 5052 - 5054

- | | | |
|-------------------------|----------------------|----------------------|
| 1. Screw M6x30 | 2. Cover collar | 3. Cover hat |
| 4. Rubber washer 6mm | 5. Rubber washer 3mm | 6. Washer 6x22 |
| 7. Nylok nut M6 | 8. Hexacon screw | 9. Washer 8x25 |
| 10. Rubber gasket | 11. Collar 13x11 | 12. Nut cover hat M8 |
| 13. Hexacon screw M8x20 | 14. Nylok nut M8 | 15. Washer 8x17 |

