



VEPRO OY

AE5155A and AE5155AUK version SCANIA
STREAMLINE 08/2013- SPECIAL 80mm
DEEPER SUNVISOR Mounting instructions

Read this first if you want to paint the sun visor!

The visor is made from PMMA plastic, which can be painted with acrylic based paints. For painting ask instructions from your paint supplier for PMMA material. The VHB double sided tape which is mounted on the visor will last the heat of the paint line oven but you must cover the tape before using any cleaner or paint on the visor.

1. Take your vehicle to a dry place and remove the original sunvisor.
2. Before tightening any screws make sure the mirror leg does not touch the sun visor. Mount the deeper sun visor on the brackets.

3. Clean the mounting area on the backside of the original sun visor's top part with brake cleaner or similar and rub the surface clean from any grease and dirt.

The mounting surface must be completely clean!



4. Remove the protection foil of the sun visors VHB-tape and carefully mount the original top part on the sun visor. **Make sure you support the backside of the visor with your hand when you push the top part on the visor.**

Make sure all the 5 mounting clips are locked and press top part against the VHB-tape.

