

1. Take your vehicle to a dry place.
2. Place the deflector on the door's rubber gasket and mark the mounting area.
3. Clean the gasket with brake cleaner or similar several times and rub the gasket's surface clean from any grease and dirt.

The mounting surface must be completely clean!



4. Mount the deflector on the door's gasket. Roll/press the deflector against the gasket for several minutes in order to attach the full area of the tape.

Let the deflector settle for 20 minutes.

Control that the deflector is fully attached on the gasket.

If the tape is not fully attached, roll and press the deflector against the gasket again.

