

TruckChef

24v Microwave

DAF XF SUPER SPACE



Part Number :- DAFXFSSP



Open centre locker
Side Bracket Fitting
Using supplied template, position and mark drilling positions for side brackets.
Drill holes in locker floor.
Fit brackets to floor of locker, using screws & nyloc nuts.
Slide microwave between brackets, locating screws in side of microwave into slots in brackets.
Push microwave backward and tighten front screw to lock into position.

Please Note: Brackets have different height options. Please select required height for your vehicle before securing bracket to locker floor

Wiring Option



Part Number :- LONGLOOM

Fitting Kit Included

