

Fitting Instructions

Mercedes Antos Top Spoiler

Have technical questions or need fitting advice?
Contact Kuda UK - 01449 744174

Step 1.



Remove both interior lights from roof lining to expose under side of cab roof. Push any wires towards the centre of the cab.

Step 2.



Position ear on roof using the moulded shape of the base to align correctly. Drill through the 2 pre-drilled holes into the cab roof.

Step 3.



Run a generous bead of sealant around both holes to help create a water tight seal.

Step 4.



Insert 1 x M8 x 25mm Bolt through the larger of the 2 holes. Secure with washer and nylock. Insert quick screw in the smaller hole at the front of the ear.

Step 5.



Attach gutter clamps and channel to the rear cab gutters as shown. Repeat steps 2 through 5 for the other ear.

Step 7.



Drill and bolt through the rear lower corners of the blade into the ear. Making sure that the spoiler is adjusted to the correct height of the vehicles body. The blade should not exceed the height of the bulk head.

Step 6.



Secure front hinging brackets to spoiler blade (do not over tighten). Then lift blade up to the roof and position and secure hinges to the pre-moulded studs in the ears.

Step 8.



Check all fixings are secure to avoid vibrations.