

MAN TG XXL / XLX



Align microwave in locker with replacement shroud panel. Drill holes in locker floor. Fit brackets to floor of locker, using screws & nyloc nuts. Slide microwave between brackets, locating screws in side of microwave into slots in brackets. Push microwave backwards and tighten front screw to lock in position. Fit replacement shroud panel around microwave, securing with self tapping screws.

Remove door from centre locker. Trim approx. 20mm from bottom edge of locker surround.

Please Note: Brackets have different height options. Please select required height for your vehicle before securing bracket to locker floor



