

MAN EURO 6 6x2 SIDESKIRTS



Bolt through mudwing and sideskirt using M8 Button Head Screws, washers & Nyloc Nuts.

Bolt through mudwing and sideskirt return using M8x35 Screws, washers & Nyloc Nuts

